

K1 hybrid Assembly procedure



Step 1



Step 2



Unscrew

Step 3



Step 4



Step 5



Screw