

# MIX<sup>®</sup> 2.0 - UPDATE PROCEDURE

## 1. INSTALLING THE DRIVERS

- Uncompress the MIX Update Software (preferably on your desktop).
- Open the folder.
- Launch **lct\_installer\_1.exe** to install the drivers.


| Name                         | Status | Date modified    |
|------------------------------|--------|------------------|
| DFUSec.exe                   |        | 18/12/2017 17:45 |
| DFUUTIL.ini                  |        | 20/08/2019 15:25 |
| iram_dfu_util_any.bin.hdr    |        | 18/12/2017 17:45 |
| <b>lct_installer_1.exe</b>   |        | 09/03/2018 13:54 |
| Mix-Update-Procedure-01.pptx |        | 20/08/2019 16:21 |

- Follow the procedure. Untick all boxes when the installation is finished. The software should close.



### Completing the LPC-Link 2 Configuration Tool Setup Wizard

Click the "Finish" button to exit the Setup Wizard.




## 2. LAUNCHING AND CONFIGURING

- Go back to the folder and launch **DFUSec.exe**:

|                              |  |                  |
|------------------------------|--|------------------|
| <b>DFUSec.exe</b>            |  | 18/12/2017 17:45 |
| DFUUTIL.ini                  |  | 20/08/2019 16:48 |
| iram_dfu_util_any.bin.hdr    |  | 18/12/2017 17:45 |
| lct_installer_1.exe          |  | 09/03/2018 13:54 |
| Mix-Update-Procedure-01.pptx |  | 20/08/2019 16:47 |


- Go to File and untick **Lock LINK2 function**:



# MIX - UPDATE PROCEDURE

## 2. LAUNCHING AND CONFIGURING (CONTINUED)

- You will arrive at the windows below. If Algo and File are greyed out, please add a step by clicking **Add Step**. If they are not greyed out, go to the next page of this procedure.




- Select the programming algorithm in the MIX Update Software folder, called **iram\_dfu\_util\_any.bin.hdr**



- Select the latest firmware you have downloaded from the website:




- Fill in the configuration options exactly like the picture below:




## 3. UPDATING


- Connect the MIX controller to a power supply. If the controller turns ON, turn it back OFF.
- Connect the MIX controller to this PC using a USB to Micro USB cable.
- Press the Red dimmer button and keep it pressed:



- Turn on the MIX controller while keeping the dimmer button pressed:




- Do not release the ON/OFF button!
- Release the dimmer button but keep the on/off button pressed.



- **Start** button will turn from grey to normal if the MIX is started properly in update mode.
- **Click the Start button in DFUsec to update the MIX:**



- Make sure the update was successful. The green bar should be full.



- Disconnect from the power supply and reconnect. Turn the controller back ON.
- To verify the proper firmware is in the MIX controller, go to SETTINGS/INFORMATION and verify the firmware version.

**UPDATE IS FINISHED, ENJOY!**